


choosing your Infratech system

STEP 1 | Measure the dimensions and mounting heights of the area you want to heat.

STEP 2 | Select the heater(s) that will work both functionally and aesthetically for your space. Consider heater size, quantity, color and mounting options.

STEP 3 | Choose the control option that works best for your space, needs and budget.



W-SERIES AND WD-SERIES HEATERS—WIDTH: 8-3/16"
SL-SERIES HEATERS—WIDTH: 4-3/4"

Need assistance? We can walk you through the process of selecting the Infratech heating system that's right for you. To learn more, or find a distributor near you, please contact us.

www.infratech-usa.com | 800.421.9455

SL=SLIMLINE SINGLE ELEMENT HEATERS
W=W-SERIES SINGLE ELEMENT HEATERS
WD=WD-SERIES DUAL ELEMENT HEATERS

Note: Indoor or well-protected environments will generally exceed average coverage. Heaters may provide less than average coverage in extremely cold or windy conditions.